# ME-372: Heat transfer and Metrology lab

# Vibration Measurement of Structure Using Accelerometer Sensor



## **Contents**

- Introduction
  - Introduction of Modal analysis
  - Objective
  - Principle
- Theory
- Procedure & Precaution
- Experimental setup
- Results
- Conclusion
- Report requirements

## Introduction

- Every structure has its
  - > natural frequencies and
  - > natural modes of vibration
- $\diamond$  Modal analysis is  $\rightarrow$  *method*
- Use?
  - resonant frequencies
  - mode shapes



People walking on the bridge

## **Introduction contd..**

### **Objectives of experiment:-**

> To measure:


the vibration of a structure using accelerometer
the impact forces applied using the impulse-force hammer

> To determine the frequency response functions for calculating the natural frequencies and modal parameters of a


vibrating structure

### Principle:-

❖ To convert the vibration signals of excitation and responses measured on a complex structure into a set of modal parameters



# **Theory**



IMPACT

Resonant Damped

Vibration

- **&** Each function is a complex function
- ❖ Represented in terms of magnitude and phase

# Theory (Contd..)


Analytical Frequency Response Function

$$\sum_{F=m\ddot{x}}^{F=m\ddot{x}}$$


$$m\ddot{x} + c\dot{x} + kx = F$$

$$\ddot{x} + 2\zeta\omega_n\dot{x} + \omega_n^2x = \omega_n^2\frac{F}{k}$$

resulting transfer function is called as receptance function



Single-degree-of-freedom system subjected to a force excitation



Free-body Diagram

The accelerance function is

 $k/m = (\omega^2_n)$ 

$$rac{X(\omega)}{R(\omega)} = rac{1}{k} (rac{\omega_n^2}{\omega_n^2 - \omega^2 + j(2\zeta\omega\omega_n)})$$

The accelerance function is 
$$\frac{A(\omega)}{F(\omega)} = \frac{1}{k} \left( \frac{-\omega^2 \omega_n^2}{\omega^2 - \omega^2 + i(2\zeta \omega_n)} \right)$$


## Schematic of actual experimental setup & components:-



Amplifier/Signal Conditioner




*Impulse-force hammer* 



Schematic diagram of experimental setup





5

Accelerometer sensor


### Fitting of Figure 4 (from MATLAB):-

Accelerance function is 
$$\longrightarrow \frac{A(\omega)}{F\omega} = \frac{1}{k} \left( \frac{-\omega^2 \omega_n^2}{\omega_n^2 - \omega^2 + j(2\zeta\omega\omega_n)} \right)$$

Knowns	Unknowns
$\frac{A(\omega)}{F(\omega)}$ , $\omega$	$oldsymbol{\omega}_{n_{,}}oldsymbol{\zeta}$ , $oldsymbol{k}$


"11.lvm file screenshot"
Such set of data files will be shared
to the students

**Example plot:** 



### **Procedure:-**

- 1. Make sure all the devices are working properly.
- 2. Divide the structure into 5 different nodes.
- 3. Each of which will be excited to completely understand the natural modes of vibration of the plate.
- 4. Identify the two nodes where you want to take the measurement using impulse hammer at one node and accelerometer at another node.
- 5. Place the accelerometer at the node where you want to measure the response.
- 6. Start the data acquisition using the run button at the computer Labview software panel.
- 7. Tap the impact hammer at the one of the selected node to excite the structure.
- 8. Save the data of acceleration and impact force which will be in **time domain**.
- 9. Repeat the process by selecting the different nodes on the structure.



Experimental setup

### **Precaution:-**

To avoid affecting the test result, care must be taken to ensure that the test is not disturbed by any shock or vibration.

# Results & Analysis (Report requirements):-

Question 1. Plot the frequency response function (FRF) for the data acquired for different nodes.

**Question 2.** Determine the *natural frequency* using these FRFs at different locations.

**Question 3.** Determine the *modal parameters* for different modes using curve fitting method.

**Question 4.** Write *conclusions* and some *potential sources of error*.

#### Remember to also attach:

- **▶** Introduction
- Objective
- Principle
- > Theory
- Procedure & Precaution

# **Report Plots:**

- Data *provided* to you will be:
  - MATLAB program("FFT\_FRF.m")
  - ➤ 10 "\*\*.lvm" files(coming from the LabView Software)
- Expected plots from <u>your side</u> will be:
  - $\geq$  <u>10</u> different fitted plots with (as shown in the side example plot)
    - **<u>legend</u>** containing the mention of

      - $\triangleright$   $\omega$
      - > <u>k</u>
    - X and Y axis label
    - Clear <u>fitted plot in red color</u> along with the data plot in the same graph
    - Title of the input file plot (e.g. mention "Exp 23" coming from the "23.lvm" file as shown)

